

Configuration des champs

help.fracttal.com/hc/fr/articles/25066622375309-Configuration-des-champs

The screenshot shows the 'Equipment' section of the Fractal Assets management interface. At the top, there is a search bar and a user profile icon labeled 'JC'. Below the search bar, there are navigation options for 'List' and 'Treemap'. The main content is a table with the following columns: 'Enabled', 'Out of Service', 'Description', 'Code', and 'NOMBRE'. The table contains 14 rows of equipment data. A context menu is open over the table, listing various actions: 'Open PDF', 'Export', 'Bulk export data', 'Print QR', 'Import', 'Delete Imported Data', 'Fields Configuration' (highlighted with a red border), 'Clone Asset', and 'Batch Edition'. At the bottom left of the table, it says 'Showing 50 of 5955'. At the bottom right, there is a blue circular button with a white plus sign.

Enabled	Out of Service	Description	Code	NOMBRE
<input type="checkbox"/>	No	{ 00001-2 } FA mantenimiento J	00001-2	FA mantenimiento J
<input type="checkbox"/>	No	{ 05 } BEBEDOURO - JOÃO LUCAS	05	BEBEDOURO - JOÃO LUCAS
<input type="checkbox"/>	No	{ 100201 } Radio	100201	Radio
<input type="checkbox"/>	No	{ 100248 } Radio	100248	Radio
<input type="checkbox"/>	No	{ 100251 } Radio	100251	Radio
<input type="checkbox"/>	No	{ 100255 } Radio	100255	Radio
<input type="checkbox"/>	No	{ 100256 } Radio	100256	Radio
<input type="checkbox"/>	No	{ 100258 } Radio	100258	Radio
<input type="checkbox"/>	No	{ 10 } brasil 10	10	brasil 10
<input type="checkbox"/>	No	{ 11101119015021 } PLC GEOFENCE	11101119015021	PLC GEOFENCE
<input type="checkbox"/>	No	{ 111019011012 } PLC Geofence	111019011012	PLC Geofence
<input type="checkbox"/>	No	{ 111019014000 } PLC Geofence	111019014000	PLC Geofence

La configuration des champs est une option qui permet de personnaliser certains paramètres dans le module des actifs, ce qui permet également de créer le champ "description" des actifs en fonction de la concaténation sélectionnée.

Comment configurer les champs ?

Pour configurer les champs, vous devez saisir la liste du type de bien dont vous souhaitez modifier les champs (il peut s'agir d'emplacements, d'équipements, d'outils, de données numériques ou de pièces détachées et de fournitures).

Assets
Equipment

Search...

Equipment

List Treemap

Enabled	Out of Service	Description	Code	NOMBRE
Yes	No	{ 00001-2 } FA mantenimiento J	00001-2	FA mantenimiento J
No	No	{ 05 } BEBEDOURO - JOÃO LUCAS	05	BEBEDOURO - JOÃO LUCAS
Yes	No	{ 100201 } Radio	100201	Radio
Yes	No	{ 100248 } Radio	100248	Radio
Yes	No	{ 100251 } Radio	100251	Radio
Yes	No	{ 100255 } Radio	100255	Radio
Yes	No	{ 100256 } Radio	100256	Radio
Yes	No	{ 100258 } Radio	100258	Radio
Yes	No	{ 10 } brasil 10	10	brasil 10
Yes	No	{ 11101119015021 } PLC GEOFENCE	11101119015021	PLC GEOFENCE

Showing 50 of 5955

Vous devez ensuite dérouler le menu des options supplémentaires et sélectionner "configuration des champs".

Assets
Equipment

Search...

Equipment

List Treemap

Enabled	Out of Service	Description	Code	NOMBRE
Yes	No	{ 00001-2 } FA mantenimiento J	00001-2	FA mantenimiento J
No	No	{ 05 } BEBEDOURO - JOÃO LUCAS	05	BEBEDOURO - JOÃO LUCAS
Yes	No	{ 100201 } Radio	100201	Radio
Yes	No	{ 100248 } Radio	100248	Radio
Yes	No	{ 100251 } Radio	100251	Radio
Yes	No	{ 100255 } Radio	100255	Radio
Yes	No	{ 100256 } Radio	100256	Radio
Yes	No	{ 100258 } Radio	100258	Radio
Yes	No	{ 10 } brasil 10	10	brasil 10
Yes	No	{ 11101119015021 } PLC GEOFENCE	11101119015021	PLC GEOFENCE
Yes	No	{ 111019011012 } PLC Geofence	111019011012	PLC Geofence
Yes	No	{ 111019014000 } PLC Geofence	111019014000	PLC Geofence

Showing 50 of 5955

- Open PDF
- Export
- Bulk export data
- Print QR
- Import
- Delete Imported Data
- Fields Configuration**
- Clone Asset
- Batch Edition

En cliquant sur Configuration des champs, le système affiche une nouvelle fenêtre dans laquelle vous pouvez modifier les champs affichés et créer le champ de description à partir de la sélection de champs disponibles.

The screenshot displays the 'Fields Configuration' page for 'Equipment' assets. On the left, a table lists equipment items with columns for 'Enabled', 'Out of Service', and 'Description'. On the right, a configuration panel allows for field customization. The fields shown are:

- Name: NOMBRE
- Make: MARCA
- Model: MODELO
- Serial number: SERIAL
- Extra 1: GARANTIA
- Extra 2: CAPACIDAD DE ALMACENAMIENTO
- Description: A dropdown menu currently showing 'MARCA Code NOMBRE Serial'.

Les champs qui peuvent être modifiés sont les suivants :

- **Nom**
- **Fabricant**
- **Modèle**
- **Numéro de série**
- **Autre 1**
- **Autre 2**

Enfin, une fois la configuration terminée, cliquez sur le bouton "Enregistrer" pour valider les modifications apportées.

Remarque : à l'exception des localisations, le champ de description peut être construit pour le reste des différents types d'actifs enregistrés dans la plateforme.