How to edit a plan’s tasks?

help.fracttal.com/hc/en-us/articles/24947323911821-How-to-edit-a-plan-s-tasks

To edit an existing task plan, just must first select the task plan in question to activate the editing option.

Access the main menu and then select the "Work Management" module. Next, choose the "Planned Maintenance" option to manage the plans associated with the assets.





Upon clicking on the editing option, the task plan will open and once there you'll only need to select the field that you want to modify (General, Tasks or Assets), finally you'll just need to save the changes made.


Work Management
Planned Maintenance
JC
PRUEBA
Save
Information
You have pending changes to save!
General
Task Plans
Assets Linked
Description
PRUEBA
Limit Acces to this location
// Fracttal/
Linked Tasks
1
Assets Linked
0