

Public QR Configuration

help.fractal.com/hc/en-us/articles/25066708725517-Public-QR-Configuration

In Fractal, you can create public QR codes that allow any user, without the need for registration, to view the maintenance history of equipment (**last 50 preventive tasks**).

Being public, the code can be scanned from any device or application, without requiring a Fractal account.

Process to configure public QR codes

To generate a public QR code, you just need to go to the general record of the asset you want to configure and then specifically to the field called “Public QR”.

The screenshot shows the 'Equipment' configuration page for an asset with ID 'FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07'. The interface includes a sidebar with navigation options: General, Custom Form, Health Status, Financial, Third Parties, and Spare Parts and Supplies. The main area contains various configuration fields. The 'Public QR' field is highlighted with a red border. Below this field, a note states: 'It only allows to add the valid format of Qr Public (https://one.fractal.com/qr/xxx)'. The 'Public QR' field has a QR code icon on the right side.

Once there, you must click on the options button that you will find in that field, where two options will be displayed:

- **Generate:** Option that allows generating a unique URL composed of “<https://one.fractal.com/qr/>” followed by a standard UUID identification code.
- **Open:** Option that allows opening the public URL associated with the asset’s guest portal.

FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Save



Out of Service: No
Enabled

General

Custom Form

Health Status

Financial

Third Parties

Spare Parts and Supplies

Serial
22222.0111.07

Voltage
110v

CAPACIDAD DE ALMACENAMIENTO

Barcode

Priority

Type

ALT

Group 1

21 BTU

Group 2

1080p

Supplier

Jonas Consult

Purchase date

2025-03-27

Hours of average daily use

24:00

Visible to all

Planned Maintenance



Public QR



It only allows to add the valid format of Qr Public (<https://one.fractal.com/qr/xxx>)

Notes

Once the options are displayed, just click on “Generate” so the system automatically creates the URL for the public QR code.

FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Save



Out of Service: No
Enabled

Information
You have pending changes to save!

General

Custom Form

Health Status

Financial

22222.0111.07

110v

CAPACIDAD DE ALMACENAMIENTO

Barcode

Priority

Type

ALT

Group 1

21 BTU

Group 2

1080p

Supplier

Jonas Consult

Purchase date

2025-03-27

Hours of average daily use

24:00

Visible to all

Planned Maintenance



Public QR

It only allows to add the valid format of Qr Public (<https://one.fractal.com/qr/xxx>)

Notes

Generate
Open

FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Save



Out of Service: No
Enabled

General

Custom Form

Health Status

Financial

Third Parties

Spare Parts and Supplies

22222.0111.07

110v

CAPACIDAD DE ALMACENAMIENTO

Barcode

Priority

Type

ALT

Group 1

21 BTU

Group 2

1080p

Supplier

Jonas Consult

Purchase date

2025-03-27

Hours of average daily use

24:00

Visible to all

Planned Maintenance



Public QR

<https://one.fractal.com/qr/ec917ef1-6609-4b8a-a38e-d47918d688a9>

It only allows to add the valid format of Qr Public (<https://one.fractal.com/qr/xxx>)


Notes

Then, click the "Save" button to keep all the changes made to the QR configuration.

Assets
Equipment

FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Save


Out of Service: No
Enabled

Information
You have pending changes to save!

General
Custom Form
Health Status
Financial

CAPACIDAD DE ALMACENAMIENTO _____ Barcode _____ Priority _____

Type: ALT Group 1: 21 BTU Group 2: 1080p

Supplier: Jonas Consult Purchase date: 2025-03-27

Hours of average daily use: 24:00 Visible to all

Planned Maintenance _____

Public QR: <https://one.fractal.com/qr/21d02514-ed36-41eb-82f4-4ce547603ae2>

Notes _____

Finally, if you want to view the guest portal associated with the asset in question, just click "Open" to open a new window with that public request portal.

FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Save



Out of Service: No
Enabled

Information
You have pending changes to save!

General

Custom Form

Health Status

Financial

22222.0111.07

110v

CAPACIDAD DE ALMACENAMIENTO

Barcode

Priority

Type

ALT

Group 1

21 BTU

Group 2

1080p

Supplier

Jonas Consult

Purchase date

2025-03-27

Hours of average daily use

24:00

Visible to all

Planned Maintenance



Public QR

<https://one.fracttal.com/qr/21d02514-ed36-41eb-82f4-4ce547603ae2>


It only allows to add the valid format of Qr Public (<https://one.fracttal.com/qr/xxx>)

Notes

Generate

Open

General asset information



FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Code

MON-FA-0001

Is part of

// Fractal/

Maker

FRUNIV

Model

05011142

Serial

22222.0111.07

Group 1

21 BTU

Group 2

1080p

Barcode

Type

ALT



Note:

- To generate the QR code image, you should use a QR code generator preferably using the created URL, then it should be printed to be installed on the desired asset.
- All requests sent through this portal will have a status that allows differentiating which requests come from this functionality, so they can be deleted if requests that do not make sense for the service provided are generated.

Assets
Equipment

FRUNIV { MON-FA-0001 } MONTADORA - FA 22222.0111.07

Save

Serial: 22222.0111.07 Voltage: 110v

CAPACIDAD DE ALMACENAMIENTO Barcode Priority

Type: ALT Group 1: 21 BTU Group 2: 1080p

Supplier: Jonas Consult Purchase date: 2025-03-27

Hours of average daily use: 24:00 Visible to all

Planned Maintenance

Public QR: <https://one.fractal.com/qr/ec917ef1-6609-4b8a-a38e-d47918d688a9>


It only allows to add the valid format of Qr Public (https://one.fractal.com/qr/xxx)

Notes


Out of Service: No
Enabled

General
Custom Form
Health Status
Financial
Third Parties
Spare Parts and Supplies

We can also associate the guest URL with the asset's internal QR code from the mobile application. To do this, go to the "Barcode" field and click on the QR code reading option. Once clicked, the reader will open, scan the QR code, and the URL will be automatically registered. Finish by clicking SAVE.



FRUNIV { MON-FA-0001 } MONTADORA - ...



Out of Service: No

Enabled

 Write NFC

 General >


 Custom Form >

 Health Status >

 Financial >

 Third Parties >

 Group De  >



Supplier

Jonas Consult



Purchase date

2025-03-27

Hours of average daily use

24:00



Visible to all

Planned Maintenance



Public QR

<https://one.fracttal.com/qr/ec917ef1->



It only allows to add the valid format of Qr Public (
<https://one.fracttal.com/qr/xxx>)

Notes

Upon detecting the QR code scan, the portal will open where you will be able to see at the bottom each of the planned tasks that have been executed for this asset. Likewise, work requests can be made for the asset in question.

General asset information



FRUNIV { MON-FA-0001 }

MONTADORA - FA 22222.0111.07

Code

MON-FA-0001

Is part of

// Fractal/

Maker

FRUNIV


Model

05011142

Serial

22222.0111.07

Group 1



Requester information

Nombre *

correo corporativo

Request information

Registre su ticket *

Registre su ticket maximum 200 characters
allowed

Equipo

FRUNIV { MON-FA-0001 } MON 

Group

