How to edit a work request already created?

help.fracttal.com/hc/en-us/articles/25052750023437-How-to-edit-a-work-request-already-created

To edit an existing work request, first locate it in the Pending column. Once you've found it, click on the request.

Upon clicking, you will be redirected to the next interface where the request information is located.

Please note the following:

1. Only requests found in the Pending column can be edited, as shown in the image.
2. The information that can be edited includes:

- **Image**
- **Asset**
- **Reference**
- **Classification 1 and 2**
- **Group**
- **Keywords**
- **Status change**
- **Comments**
- **Add attachments**