


How to enter the Work Request Analysis module?

help.fractal.com/hc/en-us/articles/25196997331981-How-to-enter-the-Work-Request-Analysis-module

To enter just go to the main menu and look for the "Business Intelligence" module.




Clicking on it will display all the associated sub-modules, where you must click again on "Work Request Analysis" to finally display the window with the work request analysis section.

Dashboard Rating Assets in Work Request

Date: 2024-09-13 / 2025-03-13

Created vs Finished Work Request

Go to Requests




141
Number Work request Created

55
Number Work request Solved

86
Number Work request Pendings

Work request by Status



Average Time For First Response

1 Day(s) 5 Hours 21 m

Average Timeout Solution

