

Public QR set up

help2.fracttal.com/hc/en-us/articles/25066708725517-Public-QR-set-up

3 months ago Updated

You will now be able to create public QR codes on Fracttal. These will allow any user without access to the platform to read the codes that are available on the different equipments, and consult the maintenance history of the asset (the last 50 preventive tasks will be shown).

Since the code is public, it can be read from any application or device and no registration or dependence on a Fracttal account is required.

Note: The guest portal add-on, combined with this feature, enables a Fracttal non-registered user to create work requests.

Process for setting up public QR codes

Under the General tab of the asset whose QR code is to be set up, you can click on the options button within the field called "Public QR".

The screenshot displays the 'General' tab for an asset named '(ROB-0001) ROBO - 0001 FANUC'. The interface includes a sidebar with navigation options like 'General', 'Custom Form', 'Health Status', 'Financial', 'Third Parties', 'Spare Parts and Supplies', 'Historical', and 'Attachments'. The main content area contains various fields for asset details, such as 'Otro 2' (380V), 'Barcode' (43534656542), 'Priority' (Very High), 'Type' (ROBO), 'Group 1' (ELECTRICO), 'Group 2' (mechanical), 'Supplier' (Servicios Electricos SA), 'Purchase date' (2024-02-22), 'Hours of average daily use' (24:00), and 'Planned Maintenance' (Plano de Tareas - Montadora Elias Corp). A red box highlights the 'Public QR' field, which is currently empty. Below this field, a small note reads: 'It only allows to add the valid format of QR Public (https://one.fracttal.com/qr/xyz)'. The 'Out of Service: Yes' toggle is set to 'Enabled'.

Two options will be displayed:

- **Generate:** Option that allows you to generate a unique ULR consisting of "<https://one.fractal.com/qr/>" followed by a standard identifying UUID code.
- **Open:** Option that allows you to open the public URL associated with the asset's guest portal.

Assets Equipment Old Version

{ ROB-0001 } ROBO - 0001 FANUC Save

32041340 1300W

Otro 2: 380V Barcode: 43534656542 Priority: Very High

Type: ROBO Group 1: ELECTRICO Group 2: mechanical

Supplier: Servicios Electricos SA Purchase date: 2024-02-22

Hours of average daily use: 24:00 Visible to all:

Planned Maintenance: Plano de Tareas - Montadora Elias Corp

Public QR:

It only allows to add the valid format of Qr Public (https://one.fractal.com/qr/xxx)

Notes:

- Click on "Generate" and the system will automatically create the URL of the public QR code.

{ ROB-0001 } ROBO - 0001 FANUC

Save



Out of Service: Yes
Enabled

Details

- General
- Custom Form
- Health Status Beta
- Financial
- Third Parties
- Spare Parts and Supplies
- Historical
- Attachments

3234 1343		15UUV
Otro 2 380V	Barcode 43534656542	Priority Very High
Type ROBO	Group 1 ELECTRICO	Group 2 mechanical
Supplier Servicios Electricos SA	Purchase date 2024-02-22	
Hours of average daily use 24:00		<input type="checkbox"/> Visible to all
Planned Maintenance Plano de Tareas - Montadora Elias Corp		
Public QR <small>It only allows to add the valid format of Qr Public (https://one.fracttal.com/qr/xxx)</small>		
Notes		

Generate
 Open

{ ROB-0001 } ROBO - 0001 FANUC

Save



Out of Service: Yes
Enabled

Information
You have pending changes to save!

Details


- General
- Custom Form
- Health Status Beta
- Financial
- Third Parties
- Spare Parts and Supplies

3234 1343		15UUV
Otro 2 380V	Barcode 43534656542	Priority Very High
Type ROBO	Group 1 ELECTRICO	Group 2 mechanical
Supplier Servicios Electricos SA	Purchase date 2024-02-22	
Hours of average daily use 24:00		<input type="checkbox"/> Visible to all
Planned Maintenance Plano de Tareas - Montadora Elias Corp		
Public QR https://one.fracttal.com/qr/6f485897-37e4-40ca-89a9-23ddc593f888 <small>It only allows to add the valid format of Qr Public (https://one.fracttal.com/qr/xxx)</small>		
Notes		

Click on the "Save" button to keep all the changes made to the QR set up.

{ ROB-0001 } ROBO - 0001 FANUC

Save



Out of Service: Yes
Enabled

Information
You have pending changes to save!


- Details
- General
 - Custom Form
 - Health Status Beta
 - Financial
 - Third Parties
 - Spare Parts and Supplies

32341343	15UUV	
Otro 2 380V	Barcode 43534656542	Priority Very High
Type ROBO	Group 1 ELECTRICO	Group 2 mechanical
Supplier Servicios Electricos SA	Purchase date 2024-02-22	
Hours of average daily use 24:00	<input type="checkbox"/> Visible to all	
Planned Maintenance Plano de Tarefas - Montadora Elias Corp		
Public QR https://one.fracttal.com/qr/6f485897-37e4-40ca-89a9-23ddc593f888		
<small>It only allows to add the valid format of Qr Public (https://one.fracttal.com/qr/xxx)</small>		
Notes		

In case you wish to view the guest portal associated with the asset in question, you can click on "Open" option to open a new window with the public request portal.

{ ROB-0001 } ROBO - 0001 FANUC

Save



Out of Service: Yes
Enabled

Information
You have pending changes to save!

Details

- General
- Custom Form
- Health Status Beta
- Financial
- Third Parties
- Spare Parts and Supplies

32341343 15UW

Otro 2: 380V Barcode: 43534656542 Priority: Very High

Type: ROBO Group 1: ELECTRICO Group 2: mechanical

Supplier: Servicios Electricos SA Purchase date: 2024-02-22

Hours of average daily use: 24:00 Visible to all


Planned Maintenance: Plano de Tareas - Montadora Elias Corp

Public QR: <https://one.fractal.com/qr/6f485897-37e4-40ca-89a9-23ddc593f888>
It only allows to add the valid format of Qr Public (https://one.fractal.com/qr/xxx)

Notes

Generate
 Open


General asset information





{ ROB-0001 } ROBO - 0001 FANUC


Code	ROB-0001
Is part of	// Montadora - Elias Corp/ USINAGEM DE MOTORES/ USINAGEM DE CABEÇOTES/
Maker	FANUC
Model	6 motors
Serial	32541345
Group 1	ELECTRICO
Group 2	mechanical
Barcode	43534656542


Task history


- { ROB-0001 } ROBO - 0001 FANUC 

Work Order: OS-459-SC
Description: Reaperto em base viva
Task type:
- { ROB-0001 } ROBO - 0001 FANUC 

Work Order: OS-314-SC
Description: Reaperto em base viva
Task type:
- { ROB-0001 } ROBO - 0001 FANUC 

Work Order: OS-312-SC
Description: Reaperto em base viva
Task type:
- { ROB-0001 } ROBO - 0001 FANUC 

Work Order: OS-311-SC
Description: Reaperto em base viva
Task type:
- { ROB-0001 } ROBO - 0001 FANUC 

Work Order: OS-310-SC
Description: Reaperto em base viva
Task type:
- { ROB-0001 } ROBO - 0001 FANUC 

Work Order: OS-309-SC
Description: Reaperto em base viva
Task type:



Note:



- To generate the QR code image, a QR code generator should be used preferably by means of the URL created. You will be able to print it and paste it on the desired asset.
- All requests sent through this portal will be distinguished meaning a specific status, so that they can be removed in case they are not relevant for the service provided.
- If you wish to link the URL of the guest portal with the internal QR code of the asset, you need to enter this URL in the "Barcode" field.

The screenshot shows the 'Equipment' page for asset '{ ROB-0001 } ROBO - 0001 FANUC'. The interface includes a sidebar with navigation options like 'General', 'Custom Form', 'Health Status', 'Financial', 'Third Parties', 'Spare Parts and Supplies', 'Historical', and 'Attachments'. The main form contains various fields for asset details:

- Asset ID:** 32341343
- Barcode:** 130UW
- Otro 2:** 380V
- Barcode:** 43534656542
- Priority:** Very High
- Type:** ROBO
- Group 1:** ELECTRICO
- Group 2:** mechanical
- Supplier:** Servicios Electricos SA
- Purchase date:** 2024-02-22
- Hours of average daily use:** 24:00
- Visible to all:**
- Planned Maintenance:** Plano de Tareas - Montadora Elias Corp
- Public QR:** <https://one.fractal.com/qr/6f485897-37e4-40ca-89a9-23ddc593f888> (This field is highlighted with a red box in the image)
- Notes:** (Empty text area)

A 'Save' button is located in the top right corner of the form.

We can also associate the guest URL with the internal QR code of the asset from the mobile app by logging in, to do this we must go to the field "Barcode" and click on the option to read QR code, once clicked the reader will open, read the QR and automatically register the URL and finish by clicking on SAVE.



Out of Service: Yes

Enabled

 WRITE NFC

Details



General





Custom Form



Health Status

Beta



Financial



Third Parties




Spare Parts and Supplies



Historical





General



Nombre de equipo

ROBO - 0001

Código

ROB-0001

Fabricante

FANUC

Modelo

6 motors

Número de serial

32541345

Otro 1

1500w


Otro 2

380V

Código de Barras

43534656542





General



Priority

Very High



Tipo

ROBO



Clasificación 1

ELECTRICO



Clasificación 2

mechanical



Proveedor

Servicios Electricos SA



Fecha de Compra


2024-02-22

Horas de uso promedio diario

24:00

Visible para todos

Desde T



General



Servicios Electricos SA



Fecha de Compra

2024-02-22

Horas de uso promedio diario

24:00

Visible para todos



Plan de Tareas


Plano de Tareas - Montadora Elias



QR Público

<https://one.fracttal.com/qr/681a91ca->





Solo permite agregar el formato válido de Qr Público (
<https://one.fractal.com/qr/xxx>)

Notas



When the QR code reading is detected, the portal will open where you will be able to visualize at the bottom each of the planned tasks that have been executed for this asset. Also, it will be possible to make work requests for the asset in question.



General asset information



{ ROB-0001 } ROBO - 0001 FANUC

Code

ROB-0001

Is part of

// Montadora - Elias Corp/ USINAGE

Maker

FANUC

Model

6 motors



Serial

Serial

32541345

Group 1

ELECTRICO

Group 2

mechanical

Barcode

43534656542

Task history

{ ROB-0001 } ROBO - 0001



FANUC

Work Order:

OS-459-SC

Description:

Reaperto em base...

Task type:

{ ROB-0001 } ROBO - 0001



FANUC

FANUC

Work Order:

OS-314-SC

Description:

Reaperto em base...

Task type:

{ ROB-0001 } ROBO - 0001

FANUC

